

FLUKE®

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Казань (843)206-01-48

Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81

Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54

Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: fku@nt-rt.ru || www.fluke.nt-rt.ru

Тестеры Fluke T5-600 для измерения напряжения, силы тока и проверки целостности цепи



The Fluke T5 Electrical Testers let you check voltage, continuity and current with one compact tool. With the T5, all you have to do is select volts, ohms, or current and the tester does the rest. OpenJaw™ current lets you check current up to 100A - without breaking the circuit. Its tough test leads stow neatly in the back of the tester, making it easy to tote the T5 in your tool pouch. Detachable SlimReach™ test probes are customized for national electrical standards. The test leads accept optional accessories such as clips and specialty probes. The optional H5 holster lets you clip the T5 onto your belt.

- Automatically measures volts ac and volts dc with precise digital resolution
- Displays resistance to 1000Ω
- Easy and accurate OpenJaw™ current measurement
- Continuity beeper
- Compact design with neat probe storage
- Rugged enough to withstand a 10-foot (3m) drop
- Detachable SlimReach™ probe tips are customized for national electrical standards
- Test leads accept Fluke accessory test clips
- 600V model
- Can stay connected much longer than solenoid type tester
- Auto off mode to conserve battery life
- Optional holster attaches to a belt and neatly stows test leads
- AC current
- Display hold

Safety Conformance

All inputs of the T5-600 are protected to EN61010-1 CAT III 600V. UL, CSA and VDE listed.

Specifications	
Jaw opening	12.9 mm (0.5 in)
Max wire size	1/0 THHN Cable
Current range ac rms	0 to 100.0 A
Accuracy ac current (50/60 Hz)	3 % ± 3 counts
AC Response	Averaging
Voltage range ac	0 to 600 V
Accuracy ac voltage	1.5 % ± 2 counts
Voltage range dc	0 to 600 V
Accuracy dc voltage	1 % ± 1 count
Resistance range	0 to 1000 Ω
Continuity beeper threshold	On at <25 Ω, off at >400 Ω
Volts indicator LED threshold	Guaranteed on by 30 V ac

Environmental Specifications	
Operating Temperature	-10 °C to 50 °C
Storage Temperature	-30 °C to 60 °C
Humidity (Without Condensation)	0 % to 95 % (5 °C to 30 °C); 0 % to 75 % (30 °C to 40 °C); 0 % to 45 % (40 °C to 50 °C)
Dust/water resistance	Yes
Operating Altitude	2000 meters max
Temperature Coefficient	0.1 x (specified accuracy)/°C (<18 °C or >28 °C)
Safety Specifications	
Overvoltage category	CAT III 600 V ac/dc (EN61010-1)
Agency Approvals	UL, CSA, and VDE
Maximum voltage	Between any terminal and earth ground

Mechanical and General Specifications	
Size	30.5 mm x 51 mm x 203 mm
Weight	300g
Warranty	Two-years
Battery Life	200 hour zinc chloride, 400 hour alkaline
Battery type	2 x AA
Low battery indicator	Yes
Current sensor opening	12.9 mm
Calibration cycle	1 year
Test leads	Type: Heavy duty, flexible leads rated for 1000V use. Field replaceable leads terminate in male shrouded banana plugs Probes: One red, one black. Detachable Slim-Reach™ probe tips Styles: TP1 Slim Reach™ Test Probes

Модель	Название	Описание
Fluke T5-600	Voltage Tester	Includes: 600V Voltage, continuity and current tester 4 mm detachable probes - Instruction sheet

Clips	
AC220	AC220 Набор зажимов типа крокодил
AC285	Зажимы типа "крокодил" AC285 SureGrip™

Test Probes	
TLK291	TLK291 Fused test probe set
TP1	TP1 Набор пробников с плоским наконечником
TP2	TP2 Набор пробников с тонким наконечником

Сумки и Чехлы	
T5-Kit	ACC-T5-KIT Accessory Kit for use with T5
C101	C101 Твердый футляр
C520A	C520A Кожаный чехол для тестера
H5	H5 Чехол для электрического тестера
C150	Мягкий переносной футляр

По вопросам продажи и поддержки обращайтесь:

Архангельск (8182)63-90-72
 Астана (7172)727-132
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89
 Иваново (4932)77-34-06
 Ижевск (3412)26-03-58
 Казань (843)206-01-48

Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Липецк (4742)52-20-81
 Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81

Новосибирск (383)227-86-73
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Пермь (342)205-81-47
 Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54

Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сургут (3462)77-98-35
 Тверь (4822)63-31-35
 Томск (3822)98-41-53
 Тула (4872)74-02-29
 Тюмень (3452)66-21-18
 Ульяновск (8422)24-23-59
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Ярославль (4852)69-52-93

Единый адрес для всех регионов: fku@nt-rt.ru || www.fluke.nt-rt.ru